DSEULTRA® STARTING WITH QUALITY.


DSE704 & DSE4120

AUTO MAINS FAILURE CONTROL MODULES

DSE704



DSE4120



The DSE704 is an Auto Mains
Failure Control Module that offers
an excellent range of engine
monitoring and protection features.
The module has been designed to
monitor engine temperature, low
oil pressure, fail to start, charge
failure, over speed and under
speed.

When the module detects a fault condition it automatically shuts down the engine. The module also includes two user configurable auxiliary inputs.

The DSE4120 module includes all the features of the DSE704 plus a tamper proof engine hours counter, engine exercise mode function and the enclosure has a closed back.

Both modules have been designed to automatically start the generator when the mains (utility) power fails. As soon as mains (utility) power is restored the modules have been designed to transfer the load back to the mains (utility) supply. The modules then instruct the engine to begin the cool down procedure and stopping sequence (user configured).

FEATURES

- Automatic mains (utility) supply monitoring
- Automatic shutdown when fault conditions are detected
- Manual start
- Engine pre-heat
- Engine monitoring and protection features
- Protected Solid State (PSS) outputs
- Front panel mounting
- Front panel programming
- Tamper proof engine hours counter
- Remote start
- LED indicators
- Configurable timers
- Configurable outputs
- Single/three phase mains sensing

BENEFITS

- Transfers between mains (utility) and generator power
- On-site module configuration to match user requirements
- Hours counter provides accurate information for monitoring maintenance and warranty periods
- Multiple engine parameters are monitored simultaneously

OPERATION

The modules are operated using the three push buttons on the front:



MANUAL – This mode is used to manually start the engine.



AUTO – This mode is used to automatically start the engine. The module will be started by the remote start signal.



STOP – This button is used to stop the engine when it is running in either manual or automatic mode.

SPECIFICATION

DC SUPPLY

8V to 35V continuous

CRANKING DROPOUTS

Able to survive 0V for 50mS, providing supply was at least 10V before dropout and supply recovers to 5V. This is achieved without the need for internal batteries.

MAXIMUM OPERATING CURRENT

170mA(12V), 280mA(24V) (DSE4120 only) 50mA (DSE704 only)

TYPICAL CURRENT

35mA(12V and 24V) (DSE 4120 only) 12mA (704 only)

ALTERNATOR INPUT RANGE

75V(L-N) to 333V AC (L-N) absolute maximum

ALTERNATOR INPUT FREQUENCY

50Hz - 60Hz at rated engine speed (minimum:75V AC L-N) (Crank disconnect from 15V L-N @ 20Hz) Overspeed +14% (+24% overshoot) Underspeed -20%

START & FUEL OUTPUTS

1.2 Amp DC at supply voltage. Switches to battery negative when active

AUXILIARY OUTPUTS

1.2 Amp DC at supply voltage. Switches to battery negative when active

DSE704 DIMENSIONS

165mm x 125mm x 29mm 6.5" x 4.9" x 1.2"

DSE704 CUT OUT

149mm X 109mm 5.9" x 4.3"

DSE4120 DIMENSIONS

171mm x 115mm x 49mm 6.7" x 4.5" x 1.9"

DSE4120 PANEL CUT OUT

154mm x 98mm 6.1" x 3.9"

CHARGE FAIL

8 Volt Charge Fail at 12 Volts, 16 Volt Charge Fail at 24 Volts

ENVIRONMENTAL TESTING STANDARDS

ELECTRO MAGNETIC CAPABILITY BS EN 61000-6-2

EMC Generic Emission Standard for the Industrial Environment BS EN 61000-6-4 EMC Generic Emission Standard for the Industrial Environment

TEMPERATURE

BS EN 60068-2-2 Test Ab to +70°C 60067-2-2 Hot Test Ab to -30°C 60068-2-1 Cold

VIBRATION

BS EN 60068-2-6 Ten sweeps in each of three major axes 5Hz to 8Hz @ +/-7.5mm, 8Hz to 500Hz @ 2gn

HUMIDITY

BS 2011 part 2.1 60068-2-30 Test Cb Ob Cyclic 93% RH @ 40°C for 48 hours

SHOCK

BS EN 60068-2-27 Three shocks in each of three major axes 15gn in 11mS

DEEP SEA ELECTRONICS PLC

Highfield House Hunmanby Industrial Estate Hunmanby, North Yorkshire YO14 0PH England

Registered in England & Wales No.01319649

DEEP SEA ELECTRONICS INC

3230 Williams Avenue Rockford IL 61101-2668 USA

TELEPHONE

+44 (0)1723 890099

FACSIMILE

+44 (0)1723 893303

VAT No.316923457

TELEPHONE

+1 (815) 316 8706

FACSIMILE

+1 (815) 316 8708

EMAIL

sales@deepseaplc.com

WEBSITE

www.deepseaplc.com

EMAIL


sales@deepseausa.com

WEBSITE

www.deepseausa.com




DSE704 & DSE4120



CONFIGURATION

The modules can be configured to match user's individual parameter settings. Configuration mode is accessed via the switch at the rear of the module. Once in configuration mode the **AUTO-LED (AUTO)** flashes rapidly.



Please refer to the installation instructions for the parameter settings and configuration details.

DEEP SEA ELECTRONICS PLC maintains a policy of continuous development and reserves the right to change the details shown on this data sheet without prior notice. The contents are intended for guidance only.



RELATED MATERIALS

DSE704 Installation Instructions

DSE4120 Installation Instructions

DSE704 Operators Manual

DSE4120 Operators Manual

TITLE

PART NO'S

053-036 057-043 053-021 057-023











