# **DSEEXTRA® BATTERY CHARGERS AND EXPANSION MODULES.**

**DSE545** 

**DSE548** 

The LED's can be configured to be

An additional LED indicates that a DC

power supply is being received. There

is also a flashing 'Link Lost' LED fitted

When using two expansion modules

to indicate any communication

problems with the host module.

together each module should be

done by positioning the selector switch on the rear of each module.

identified as either 'A' or 'B'. This is

• Extinguish on command

· Light on command

either:

# DSE545 & DSE548

LED EXPANSION CONTROL MODULES

10		
3	9.	
1	10-	
18	3.	
		DSE545



The DSE545 and DSE548 are LED expansion modules for the DSE52xx, DSE53xx and the DSEPower® Series.

The modules have been designed to display a maximum of eight local or remote (max 50 metres) individual LED indications.

The DSE545 is presented in a horizontal enclosure and the DSE548 is presented in a vertical enclosure.

#### FEATURES

- Eight configurable LEDs
- Works up to 50 meters from the host module
- Two modules can be linked together to provide 16 LED indicators
- Interconnecting FCC 68 cable for quick installation

#### **OPERATION**

The LED's are configured using the host module and the appropriate PC software interface.

DSE

(R)

# SPECIFICATION

### DC SUPPLY

Powered from the plant battery or from a low voltage supply between 8V and 35V continuous. It is able to survive 0V for 50ms during cranking, providing supply was at least 10V before dropout and recovers to 5V. This is achieved without the need for internal batteries.

MAXIMUM OPERATING CURRENT 20mA @ 12V, 26mA @ 24V

MAXIMUM STANDBY CURRENT 107mA @ 12V, 113mA @ 24V

A OR B MODE SELECTOR Recessed Jumper Selector on rear

DSE545 DIMENSIONS 72mm x 144mm x 59mm DIN rail mounted housing 2.8" x 5.7" x 2.3"

DSE548 DIMENSIONS 144mm x 72mm x 59mm DIN rail mounted housing 5.7" x 2.8" x 2.3"

**DSE545 CUT OUT** 68mm x 138.5mm 2.7" x 5.5"

**DSE548 CUT OUT** 138.5mm x 68mm 5.5" x 2.7"

INDICATIONS Power On LED Link Lost (to controller) LED Flashing 8 Configurable LED's

#### CONFIGURATION

The module will automatically respond to signals from the host module. The module must be configured via the host module and a PC. The Expansion LED's are numbered from 1 to 8 and appear on the output configuration menu.

# ENVIRONMENTAL TESTING STANDARDS

#### ELECTRO MAGNETIC CAPABILITY (EMC)

BS EN 61000-6-4 EMC Generic Emission Standard for the Industrial Environment BS EN 61000-6-2 EMC Generic Immunity Standard for the Industrial Environment

#### ELECTRICAL SAFETY

BS EN 60950 Safety of Information Technology Equipment including Electrical Business Equipment

#### TEMPERATURE BS EN 60068-2-2

Test Ab to 70°C Test Ab to -30°C

# 

BS EN 60068-2-6 Ten sweeps in each of the three major axes 5Hz to 8Hz @ +/- 7.5mm

# 

BS EN 60068-2-30 Test Db 95% RH @ 55°C for 12 hours

#### SHOCK

BS EN 60068-2-27 Three shocks in each of three major axes 15gn in 11mS

#### DEEP SEA ELECTRONICS PLC

**Highfield House** Hunmanby Industrial Estate Hunmanby, North Yorkshire YO14 0PH England

Registered in England & Wales No.01319649

# DEEP SEA ELECTRONICS INC 3230 Williams Avenue

Rockford IL 61101-2668 USA

**RELATED MATERIALS** 

DSE5210 manual

DSE5220 manual

DSE5310 manual

DSE5320 manual

DSE5210 & DSE 5220 data sheet

DSE5310 & 5320 data sheet

52/53xx Software Manual

TITLE

#### TELEPHONE +44 (0)1723 890099

FACSIMILE +44 (0)1723 893303

VAT No.316923457

TELEPHONE +1 (815) 316 8706

FACSIMILE +1 (815) 316 8708

PART NO'S

055-037

053-023

057-016

055-038

057-013

057-014

057-006

EMAIL sales@deepseaplc.com

WEBSITE www.deepseaplc.com

EMAIL

sales@deepseausa.com

WEBSITE

www.deepseausa.com

TITLE DSE5510 data sheet DSE5510 manual DSE5520 data sheet DSE5520 manual DSE5560 data sheet DSE5560 manual 55xx Software Manual



(R)

# PART NO'S 055-039 057-015 055-040

057-016 055-041 057-017 057-007

DEEP SEA ELECTRONICS PLC maintains a policy of continuous development and reserves the right to change the details shown on this data sheet without prior notice. The contents are intended for guidance only.

